



Instruction Disclaimer

Dennis Kirk provides instructions to help our customers better understand how to install the products we sell. The instructions are exact copies of what the manufacturer includes with the product being sold.

That means the quality and accuracy of the instructions is solely dependent on what the manufacturer produces. We do our best to make the text legible and the pictures viewable. However, the end result depends largely on the quality of instructions the manufacturer provides.

Therefore, you will find that some instructions are not of the highest quality. Sometimes text is hard to read and pictures are not easy to see. At times you will find the overall look of the instructions to be less than professional. However, we feel it is better to provide what we have rather than provide nothing at all.

To the best of our knowledge the instructions and application information contained in the instructions is accurate. However, Dennis Kirk assumes no liability related to any errors that may be contained in the copy of the manufacturer's instructions we provide. Buyers are solely responsible to insure that product use is consistent with their application.

If you have any questions please contact us at customerservice@denniskirk.com or 800-969-7501 so we can further assist you regarding additional product information or any other business related questions.

Thank you for doing business with Dennis Kirk.



RACK INSTALLATION INSTRUCTIONS FOR MUD4880

Hardware:

- (4) U-Clamps
- (4) 5/16" x 2-1/2" Hex Bolts
- (4) 5/16" Nylock Nuts
- (4) 5/16" SAE Flat Washers
- (4) 5/16" USS Flat Washers
- (4) 3/4" x 3/4" Plastic Spacers
- (4) 3/4" x 3/4" Square Plastic Tube End Plugs

STEP 1: Insert the square plastic end plugs in the open end of the tubes and lightly tap in.

STEP 2: Position front rack on factory rack. Square end faces the driver. Center rack from side to side on the factory rack.

STEP 3: Position u-clamps around factory rack tubing and align with the diamonds hole in mesh rack. Use the plastic spacer between the u-clamp and the mesh. Place the larger of the washers on the bolt and then place the bolt down through the basket, spacer and u-clamp using the small washer on the bottom with the nylock nut. Do this in four locations and tighten.

