



Custom Dynamics® TruFLEX® Side Mount Kit Installation Instructions

We thank you for purchasing the Custom Dynamics® TruFLEX® Side Mount Kit. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: TF-SMK

Package Contents:

- 12" 3M Tape (1)
- 12" Black Liner (1)
- Adhesive Primer (1)



Fits: For use with TruFLEX light bars

Installation:

1. Choose the side of TruFLEX® to be mounted.
2. Apply generous amount of adhesive primer to the side to increase tape adhesion. Allow 3-4 minutes to dry.
3. Cut and place appropriate amount of 3M tape on selected side of TruFLEX®.
4. Use black liner to cover original Bottom 3M tape location by removing Red Liner and applying black liner over tape surface, press firmly.
5. Remove the Red backing from the Tape and carefully mount in the desired location, paying attention to the desired level and center. Take care in this step as once the tape adheres to the surface, it will be very hard to remove and re-apply and is not recommended.
6. Follow instructions on TruFLEX® to mount to vehicle.