



Delphi 3 Pin connector to Trailer 4 Pin Flat Connector

Thank you for purchasing XTC's **UNI-3PIN-TRAOUT** Plug & Play Trailer Power Adapter for Powering small trailer lights with a 4 terminal flat molded connector, it also includes License Plate Light or Whip Light power out.

1. Unplug OEM rear light harness.



Ranger-900 Center Rear over eng.



RZR-XP14 Drivers Side Rear Corner



Honda 1000 Remove either Taillight

2. Plug the adapter into both OEM connectors, In and Out, on the Honda Remove either Taillight and install Harness.

WARNING! Keep power wire away from any hot or moving parts.

WARNING! Do not exceed the overall power out of the OEM Brake Light or Tail Light system, it is only for low wattage LED lights.

3. Run the wire down to the trailer hitch.
4. Using the supplied cable tie's, secure the Harness to the car once again making sure that it is kept away from any hot or moving parts.

For more details on installation go to www.xtcinstall.com

We can also be reached by email at support@xtcmotorsports.net
To purchase Accessories please visit our web site at www.xtcpowerproducts.com

Copyright © 2016 XTC MOTORSPORTS LLC, all rights reserved.

XTC Power Products
A Division of XTC Motorsports LLC
925 N McQueen RD. #101
Gilbert AZ 85233
480-558-8588
www.xtcpowerproducts.com