

Instruction Disclaimer

Dennis Kirk provides instructions to help our customers better understand how to install the products we sell. The instructions are exact copies of what the manufacturer includes with the product being sold.

That means the quality and accuracy of the instructions is solely dependent on what the manufacturer produces. We do our best to make the text legible and the pictures viewable. However, the end result depends largely on the quality of instructions the manufacturer provides.

Therefore, you will find that some instructions are not of the highest quality. Sometimes text is hard to read and pictures are not easy to see. At times you will find the overall look of the instructions to be less than professional. However, we feel it is better to provide what we have rather than provide nothing at all.

To the best of our knowledge the instructions and application information contained in the instructions is accurate. However, Dennis Kirk assumes no liability related to any errors that may be contained in the copy of the manufacturer's instructions we provide. Buyers are solely responsible to insure that product use is consistent with their application.

If you have any questions please contact us at customerservice@denniskirk.com or 800-969-7501 so we can further assist you regarding additional product information or any other business related questions.

Thank you for doing business with Dennis Kirk.



Honda Pioneer Switch Dash Plate

PARTS LIST

| FIG. | QTY. | DESCRIPTION |
|------|------|----------------------|
| 1 | 1 | Black Dash Plate |
| 2 | 1 | Optional Cover Plate |
| 3 | 4 | Mounting Screws |

NOTE: WILL NOT WORK ON DELUXE MODELS.

- 1. Drill out the rivets holding the warning plate to the dash and remove the warning plate.
- 2. Hold the black switch plate in place and using a marker, mark out the switch areas that need to be cut out. Remove the switch plate and extend the marker cut line out another 1/4" for extra clearance.





- 3. Using a cutting wheel or sharp, hot utility knife, cut out the holes in the dash panel. After cutting, hold the dash plate in place to verify all the switch mounting holes are clear.
- 4. Screw the dash plate(s) in place using the included screws. Be careful not to overtighten the screws.



For installation questions or assistance call 651-983-7823.